

MK-II-W MANUAL




Read this manual carefully before use and keep for future reference. Visit www.moon-sport.com for manual updates.

FEATURES

- 1 (30 chips) COB high brightness white LED
- Mode memory function
- Auto safe mode
- 3 steady modes, 4 flashing modes
- Rechargeable lithium polymer battery (3.7V 500 mAh)
- Fits round bars from 20-52 diameters
- Low battery, charging and fully charged indicator
- Automatic fully charged cut-off system
- Side visibility
- Recharge time 2hrs
- Water resistant (IPX 4)


CONTENTS

- MK-II-W
- MK2-PP-00 (Rubber Pad)
- 3 O-rings for mounting
 - RS-D (fits 20-26mm diameters)
 - RS-E (fits 26-35mm diameters)
 - RS-F (fits 35-52mm diameters)
- USB-MICRO (USB cable)




OPERATION

1. Press power button to turn on the light,
2. Press power button to choose modes,
3. Double click power button to toggle between steady and flashing modes,
4. Press power button for 1 sec to turn off the light.



* With Mode Memory Function: the light resumes previous mode upon next usage.




RUNTIME


	Mode1	Mode2	Mode3	FL1	FL2	FL3	DAY FL
LUMEN	30	60	120	50	120	120	240
H:MIN	5:30	2:30	1:30	17:00	7:00	11:00	21:30
1M LUX	15	26	44	/	/	/	/
2M LUX	4.3	7.5	12.5	/	/	/	/



RUBBER PAD INSTALLATION





MK2-PP-00



HANDLEBAR MOUNTING

1. Choose the strap to fit in the handlebar,
2. Make sure the strap is click in place of the hook,
3. Hold the light on the seat handlebar,
4. Wrapping rubber strap around bar and stretching strap around hook to secure.



LOW BATTERY AND CHARGING INDICATOR

Low battery

- ⚡ * Steady Orange

Auto safe

- ⚡ * Flashing Orange

Charging indicator


- ⚡ * Flashing Orange - charging
- ⚡ * Steady Orange - charged

AUTO SAFE MODE

To preserve battery when power is low, the light will enter safe mode with less light output for extra 1 hour. Safe mode cannot be override. Recharge battery for maximum performance.

BATTERY CHARGING AND CARE

1. Turn off the light,
2. Lift the rubber cover,
3. Plug the USB cable into charging port,
4. Plug the USB cable to wall or computer USB socket,
5. Charging indicator will be on, Unplug the cable after fully charged.



BATTERY CARE

- * Do not charge over 5V, the battery will result in damage.
- * Keep away from flammable objects while charging as this may lead to fire or battery explosion.
- * Battery may get high temperatures during charging (up to 104°F/40°C). The battery capacity may become ineffective about 80% of its value after 300 charge/discharge cycles.
- * The battery voltage and capacity decrease apparently at low temperatures, especially near or below ice point. The capacity decreases 5%-10% at freezing (burn time decreases 50%). At -20°C, the capacity decreases 30% (burn time decreases 70%). The battery performance will return normal when the temperature gets up to 70°F/20°C.
- * Keep the battery in cool and dry place when storing. Recharge the battery fully at least every 3 months.

⚠ WARNING

- * Understand country lighting laws and regulations before use.
- * Do not shine directly in the eyes.
- * Light may get hot when in use.
- * Adjust the angle downward to prevent from blinding the oncoming vehicles on the public roads.
- * Do not submerge the battery or the whole light into water.
- * Unplug the light, charger and cable once the battery is fully charged.
- * Do not dismantle the light which will void warranty.
- * Do not leave the light on and unattended.
- * Keep the light away from fire and combustible materials.
- * Do not store head unit when hot or straightway after use.

WARRANTY

MOON Lights are covered by a ONE YEAR LIMITED WARRANTY from the date of purchase is free from defects in material and workmanship. This warranty does not apply to damage due to heat, physical damage resulting from abuse, neglect, improper repair, improper fit, or alterations of the fixture. This covers the lights and cables only. Batteries are covered by 120 days warranty not including battery normal wear.

All customers should contact the local dealer or regional distributor for warranty service. To make a claim, first contact original dealer or distributor. Some issues may be resolved upon the initial call. If return of the product is necessary, use traceable method such as FedEx or UPS, MOON is not responsible for lost or misdirected packages.

Please include your full contact information (name, address, phone number, and email [if applicable]), and a description of the issue.

For more information please contact us at cs@moon-sport.com