


# ORION-W

MANUAL

Read this manual carefully before using and keep for future reference. Visit [www.moon-sport.com](http://www.moon-sport.com) for manual updates.

## CONTENTS



ORION-W



RB-29-W  
(MAGNETIC MOUNT)



STRAPS  
RS-G  
20-35 mm




RS-H  
35-52 mm



USB-MICRO  
(USB CABLE)

## OPERATION



ON / OFF : Press 1s


MODE SELECT : Click

\* Mode memory: The light resumes previous mode upon next usage.

## RUNTIME

ANSI FL1	MODE1	MODE2	FLASH 1	FLASH 2	DAY FLASH
LUMEN	20	40	20	40	100
H:MIN	6:30	3:00	64:00	31:30	36:30

## MOUNTING




## AUTO SAFE MODE



To preserve battery when power is low, the light will enter safe mode with less light output for extra **3 hours**. Safe mode cannot be override. Recharge battery for maximum performance.

## CHARGING



### CHARGING

1. Power off
2. Plug USB cable to USB port
3. Unplug after fully charged

\* Do not charge over 5V.

\* Keep away from flammable objects while charging.

### INDICATOR

- Low battery
- Auto safe
- Charging
- Fully Charged

## WARNING

Understand country lighting laws and regulations before use.  
Do not shine light directly into eyes.  
Do not mount near wireless computer.  
Do not blind the oncoming vehicles. Always adjust the angle downward.  
Do not submerge the light into water.  
Keep light in cool and dry place when storing.  
Fully recharge the light at least every 3 months during storage.

## WARRANTY

MOON lights are covered by a ONE YEAR LIMITED WARRANTY while MOON batteries are covered by 120 days warranty from the date of purchase. This warranty covers the defects in material and workmanship only with proof of purchase. Please contact original dealer for warranty service. For lights bought on MOON website, please contact [cs@moon-sport.com](mailto:cs@moon-sport.com) for help.

### ONLINE WARRANTY REGISTRATION

Visit [www.moon-sport.com](http://www.moon-sport.com) for online warranty registration.