## **AIOLOS-HP** HAND PUMP



COMPATIBLE LOCKABLE HANDLE



CNC ALUMINUM CASING





160 11

bar



## Instruction

- 1. Turn pump handle in unlock / lock position
- 2. Open dust cap and unscrew hose
- 3. Match Presta (French) or Schrader (American) valve with correct end of hose
  - 4. Thread onto open valve, then pump to inflate

