

AIOLOS DUAL

HAND PUMP



160

MAX
PSI


11

bar

Instruction

HAND PUMP

1. Turn pump handle in unlock / lock position
2. Match Presta (French) or Schrader (American) valve with correct end of hose
3. Thread onto open valve, then pump to inflate



CO₂ INFLATOR

1. Compatible with threaded 16g cartridge only. Open dust cap and thread the CO₂ cartridge into the place, but do not over-tighten.
2. Engage with the tyre valve.
3. Hold the pump handle, unthread the gas cartridge by no more than 1/2 turn to inflate. When the tyre has seated, next thread in the CO₂ cartridge firmly.

